




F.G.1


NAME	EXTENSION NUMBER	
YAMAMOTO	5621	
SASAKI	5625	

FIG.2
















FIG.7









F I G. 11





FIG. 13










FIG. 15








F I G. 17






















FIG. 25











FIG. 28










## KEY SERVICE UNIT CONTROL FLOW CHART START 24a RECEIVE FUNCTION NUMBER SIGNAL FROM TERMINAL "0000" 24b INFORM COMPUTER OF ACTIVATION (OFFHOOK) OF **SERVICE END** 2 **START** 24c RECEIVE CHANNEL NUMBER MESSAGE SIGNAL FROM COMPUTER 24d CONNECT CHANNEL IN DIRECTION FROM COMPUTER TO KEY SERVICE UNIT 24e SEND CHANNEL CONNECTION COMPLETION MESSAGE TO COMPUTER 24f **GUIDANCE** SELECT CHANNEL IN DIRECTION FROM KEY SERVICE MESSAGE UNIT TO COMPUTER 24g INFORM COMPUTER OF CHANNEL NUMBER IN DIRECTION FROM KEY SERVICE UNIT TO COMPUTER VOICE (DIAL) **END** START 24h RECEIVE DIAL INFORMATION FROM COMPUTER 24i EXECUTE DIALING PROCESS FROM TERMINAL 000 **END**

FIG. 32A









TERMINAL CORRESPONDEN	ICE TABLE	
TERMINAL 000	MEDIA BUS LOGICAL CHANNEL	010
TERMINAL 001		011
TERMINAL 002		012
		1
TERMINAL 00n		XXX


FIG. 35

DATA HIGHWAY CORRESPONDANCE TABLE

FIG. 36 DHWY 015










FIG. 40

